

KITE INSTRUCTIONS

Kite Assembly

1. Unfold kite and separate direct lift control bridle from front bridle
2. Install struts into centerpiece
3. Attach kite corner tips to socket of spars
4. Make sure bridles are not wrapped around spars, tips or centerpiece (excessive roll in flight will occur if these conditions exist)

Before Launching Kite


Recommended kite tow line, 50 lb - 100 lb braid, extra light to heavy wind 5 - 25 mph

1. Make sure direct lift bridle is not wrapped around struts or centerpiece
2. Make sure front bridle is not wrapped around kite tip sockets
3. Adjustable bridle slide is set for wind condition
4. Be sure tow line is secured to kite

Bridle Flight Adjustment

Notes:

- Fly up - move bridle slide up
- Fly down - move bridle slide down
- Fine height adjustments should be made with 1/8" movements
- High Wind Kites will perform in extra heavy winds with conditions and limitations (88607, 88611-1)
- Light Wind and All Purpose Kites may be flown with a Tigress helium balloon and Tigress kite thong in light wind situations (88611, 88607-2, 88608, 88608-1)
- Extreme pressure on kite may cause kite tow line to break - kite retrieval will be difficult
- If kite rolls excessively, refer to Before Launching Kite instructions
- Always rinse kite with fresh water after each use, as salt water will affect flight characteristics
- If kite is submerged, stop boat and retrieve kite gently



Direct Lift Control Bridle
(Top Back View)



Top Tip Strut Socket
(Back View)



Direct Lift Control Bridle
(Back View)

TIGRESS
OUTRIGGERS & GEAR
TigressOutriggers.com

